

Valve Types

EPDM 5623 100 830-xxx S - SS 5624 100 830-xxx SS - SS HNBR 5623 100 820-xxx S - SS 5624 100 820-xxx SS - SS



Field of application

The piggable double seat valve is suitable for use as a leakproof shut-off valve in plants in the food and beverage, in pharmaceutical, biotechnological and chemical industries.

## **ATTENTION**

To avoid danger and damage, the fitting must be used in accordance with the safety instructions and technical data contained in the operating instructions.

Safety Instructions

### DANGER

- Danger of crushing or amputating limbs.
  - Do not reach into the valve housing when in pneumatic mode.
- When removing the valve or valve components from the system, there is a danger of injury from escaping liquids or dases.

Only dismantle when you are absolutely sure that the system is depressurized and free of liquids and gases.

· Danger of scalding and burns to parts of your body from liquids escaping from the leakage drain.

The splash protection fixtures must always be attached to the leakage drain.

· The actuation can be dismantled.

Danger of injury by prestressed pressure spring. Observe separate installation instructions.

We recommend having the manufacturer do the maintenance work required for the actuation.

## **ATTENTION**

- To avoid air leaking, only use pneumatic connection parts that have an O-ring seal facing the even surface.
- · When mounting the clamps, the max. torgue must not be exceeded (see technical Data).

## Function

The valve is opened from bottom to top by means of control air, and is closed from top to bottom by means of spring power without any loss of product. The upper and lower valve chambers are separated during infeed in a leak-proof fashion with two, independently closed valve discs when different media flow through the valve. Leakage which occurs due to damaged valve disc seals is discharged into the atmosphere without pressure via the leakage outlet.

The lower valve case can be cleaned with the pipework.

#### NOTE i

During the pigging process, the valve mustn't be opened and the lower valve disk mustn't be lifted respectively, because these functions obstruct the pig passage.

When selecting the pig type, please note that the pig has a double sealing design with the distance dimension "A" (fig. 3). We recommend to apply the product 7079.

# **Operating Instructions** Translation of the original 562x 100 8xx-K604

## Double seat valve DN100

piggable / rinsable EPDM / HNBR with control head KI-Top ASi-Bus ES/ABSL

## Installation instructions

During installation or production processes avoid effects of external force on the housing.

The double seat valve must be installed vertically with the actuator at the upwards. Liquid must be able to flow freely from the valve housing and the leakage chamber.



### NOTE

The valve is closed by spring pressure. An additional pneumatic boosting of the closing pressure is prohibited on account of the damage that may ensue.

## Welding Guidelines

- Sealing elements integrated in weld components must generally be removed prior to welding.
- To prevent damage, welding should be undertaken by certified personnel (DIN ISO 9606-1).
- Use the TIG (tungsten inert gas) welding process.
- NOTE (i

## Special features valve control

Optionally, modular valve control systems can be installed to the actuator for reading and actuating valve positions. The standard version is a closed system with SPS or ASI-bus switch-on electronics, and integrated 3/2-way solenoid valves. For tough operating conditions we recommend employing a high-grade steel cover.

## Maintenance

The maintenance intervals depend on the operating conditions "temperature, temperature-intervals, medium, cleaning medium, pressure and opening frequency". We recommend replacing the seals every 1 years. The user, however should establish appropriate maintenance intervals according to the condition of the seals.

## □ Cleaning

Cleaning of the housing is performed with the pipe cleaning system. As part of the cleaning program, the leakage chamber and the drain pipe can be cleaned by cycling the valve discs. The valve disc shaft is also cleaned when the upper valve disc is cycled.

Alternatively, the leakage chamber and the shaft of the upper valve disk can be cleaned by means of the external rinsing connection (ESP). For cleaning the shaft, the upper valve disk has to be lifted.

### Leakage Chamber Cleaning Parameters <sup>1)</sup>

Cleaning step	Aerate Valve Disc	Rinse Qua.	
Pre-Rinse		clocking	
80° C Wash	3 times, 5 sec. ea.	at top 7,5 m <sup>3</sup> /h	
Intermediate Rinse	2 times, 5 sec. ea.	clocking	
Acid	3 times, 5 sec. ea.	at bottom 4,5 m³/h (3bar)	
Final Rinse	2 times, 5 sec. ea.		

1) Recommended for the Beverage Industry



Horstring 16

D - 76829 Landau **2** +49 (0) 6341 5105-0

www.guth-vt.de

Fax: +49 (0) 6341 5105-85

Impurities can cause damage to the seals. Clean inside areas prior to assembly.



Guth Ventiltechnik GmbH Horstring 16 D - 76829 Landau ☎ +49 (0) 6341 5105-0 Fax: +49 (0) 6341 5105-85

> www.guth-vt.de sales@guthventiltechnik.de

Technical data

Model:		double seat valve piggable		
Valve size:		DN 100		
Connection:		welding end DN 100 DIN EN 10357		
Torque:		Retaining clamp DN100: max. 55Nm		
Temperature:		+95°C medium dependent		
Operating pressures:		operating press cleaning press	sure = ure =	6 bar 4 bar
Vacuum:		1,5 x 10 <sup>-6</sup> mbar $L/S$ (test pressure 0,5 mbar)		essure 0,5 mbar)
Control air pressure:		5,0 - 8,0 bar		
Quality of control air: ISO 8573-1: 2001 quality class 3		ty class 3		
Material:	in prod	luct contact	not in p	roduct contact
Stainless steel: 1.4404		/ ASI316L	1.4301/	ASI304
Surface:	RA 0,8	um	RA 1,5 -	∙ 2,5µm E-pol.
Seal:	EPDM HNBR	(FDA)140°SIP (FDA)130°SIP	NBR	

KV-values:	Direction of Flow		(m³/h)
	through-flow at top	⇔	380
	through-flow at bottom	⇔	390
	from bottom to top	2	155
	from top to bottom	Ľ	150



# Operating Instructions Translation of the original 562x 100 8xx-K604

Double seat valve DN100

piggable / rinsable EPDM / HNBR with control head KI-Top ASi-Bus ES/ABSL

## □ Pneumatic valve actuation

Valve function	Pneum. control with integrated MV in control unit	Pneum. control
valve "OPEN"	control air feed → P → MV1 → LA1	control air feed
valve "CLOSE"	de-aeration → LA1 → MV1 → R valve is closing by spring	de-aeration → LA1 → ext.MV valve is closing by spring
cycle lower piston	OPEN = control air feed → P → MV2 → LA2 Direct coupling	OPEN = control air feed → ext.MV → P → LA2 Direct coupling
(clean leakage chamber)	CLOSE = de-aeration → LA2 → MV2 → R valve is closing by spring	CLOSE = de-aeration LA2 P + ext.MV valve is closing by spring
cycle lower piston	OPEN = control air feed → P → MV3 → LA3	OPEN = control air feed → ext.MV → LA3
(clean leakage chamber and clean shaft)	CLOSE = de-aeration → LA3 → MV3 → R valve is closing by spring	CLOSE = de-aeration

MV = 3/2 solenoid valve LA = co

LA = compressed-air inlet (actuation)

 $\mathsf{R} \quad \texttt{= de-aeration, sound absorber} \quad \mathsf{P} \quad \texttt{= compressed-air inlet (control unit)}$ 





Guth Ventiltechnik GmbH Horstring 16 D - 76829 Landau ☎ +49 (0) 6341 5105-0

> Fax: +49 (0) 6341 5105-85 www.guth-vt.de

sales@guthventiltechnik.de

#### □ Disassembly and assembly Istalling to / Removing from the Pipe System

### 

All threaded joint have right-hand thread.

#### Disassembly

- Unscrew and remove control air and electrical lines, complete repeater mechanism and control head, steaming and cleaning lines.
- Unscrew the upper retaining clamp (30).
- Remove pneumatic valve insert (20) along with insert (15) from the top of the housing.

#### Removing in product contact wearing parts

 We recommend to use for the assembly / disassembly the assembling tool kit. stock number: 5670.100.100-000

Mounting lever	Insert	Mounting plate
Socket spanner	Eccentric ring	Hook wrench

- Unscrew the lower retaining clamp (30).
- Remove the housing bottom (1).
- Unscrew the lower piston (4) from the upper piston (11).
- Take off the split washer (12).
- Clamp the mounting plate into the vice.
- Unscrew hexagon screw (18)(4x).
- Push lantern (17) in direction "X" until the hole (C) is freely visible.
- Unscrew the piston (11) with a headed wrench (SW), counter with a hook wrench at the hole (C).
- Push the insert (15) off of the piston (11) away from the valve disc.
- According to execution position the piston (11) about the holes (B)(2x) (in the piston plate) with the retention pin (Fig.4).
- Unscrew the piston (11) with the assembly lever or headed wrench (SW) from the upper piston plate (2).
- Remove the seal (9) and the O-Ring (8) and (10).
- Dismount the valve lift stop (19) in direction "X".
- Dismantle the seals: Pos.(3)(3x), Pos.(6), Pos.(14), Pos.(27), Pos.(28), Pos.(29)(2x), Pos.(31).

## NOTE

Puncture the seals item (6) and item (8) at the centre with a pointed tool and remove them carefully from the groove.

#### Assemble

- Assemble in reverse order.
- Thoroughly clean and slightly lubricate mounting areas and running surfaces.



- Fit valve insert carefully into the casing. When fitting the valve insert and running surfaces onto the piston, do not damage.
- The casing cover (1) is positioned position dependent with a cylindrical pin in the casing (5).

# Operating Instructions Translation of the original 562x 100 8xx-K604

### Double seat valve DN100

piggable / rinsable EPDM / HNBR with control head KI-Top ASi-Bus ES/ABSL

#### > Assemble Seal (9)

- Screw in piston plate (2) without seal to the metal limit stop in the piston (11) and make a coloured mark (Fig. 5).
- Screw out the piston plate (2) of the piston (11).
- Push the seal (9) into the piston (11) and screw the piston plate (2) into the piston (11) by hand.
- Position the eccentric ring on the seal (9) (Fig. 4).
- Clamp the mounting plate into the vice and fix the piston plate (2) (see Fig. 4).
- Position the mounting lever (see Fig. 4) and screw the piston (11) up to the final limit mark (Fig.5).

#### 

EPDM; FKM; k-flex NBR; HNBR; Silicone Thread **NOTE**  Klüber Paraliq GTE 703 Klüber Paraliq GB 363 Teflongrease Interflon

## 

Check valve functions by manually activating the 3/2way solenoid valves after assembly.



Fig. 4



## Operating Instructions Translation of the original 562x 100 8xx-K604 **Double seat valve DN100**

piggable / rinsable EPDM / HNBR with control head KI-Top ASi-Bus ES/ABSL

□ Spare parts list

14.000	Designation	in product contact seals		
Item		EPDM	HNBR	
	Valve S - SS	5623 100 830-041	5623 100 820-041	
	Valve SS - SS	5624 100 830-041	5624 100 820-041	
1	Casing cover 1.4404	5623 100	825-040	
2	Piston plate 1.4404	5621 100	006-040	
3	O-Ring (3x) Ø117x3,5	2304 117 035-159	2304 117 035-050	
4	Piston bottom 1.4404	5622 100	) 824-040	
5	Housing 1.4404	S - SS 5623 100 821-041		
		SS - SS 5624	100 821-041	
6	O-Ring Ø88,27x5,33	2304 088 053-084	2304 088 053-157	
7	Plain bearing XSM	8050 020	007-156	
8	O-Ring Ø85,32x3,53	2304 085 035-159	2304 085 035-157	
9	Seal	5621 100 010-084	5621 100 010-157	
10	O-Ring EPDM	2304 036	020-170	
11	Piston 1.4404	5621 100	007-040	
12	Split washer DIN127	8072 008	3 001-020	
13	Threaded bolt M6x30 1.4301	8112 008	3 030-020	
14	Seal	5622 100 010-069	5622 100 010-050	
15	Insert 1.4404	5622 100	005-040	
16	Bearing bush PTFE	5622 100	006-053	
17	Lantern 1.4301	5624 100	512-021	
18	Hexagon screw M8x16 (4x) 1.4301	8106 008	016-020	
19	Valve lift stop 1.4305	5622 100	009-220	
20	Pneum. Actuator	5620 100	000-021	
21	Puls generator kompl.	5620 100	005-K000	
22	O-Ring Ø12x2 NBR	2304 012	2 020-055	
23	Position indication red	5622 100	058-151	
24	Cap 1.4305	5622 100	071-220	
25	One-way restrictor	8218 001	020-000	
26	Rapid action hose coupling R1/8	8217 000	004-000	
27	O-Ring Ø46x2,5 NBR	2304 046 025-055		
28	O-Ring Ø91,67x3,53 EPDM	2304 092	2 035-159	
29	O-Ring Ø40,87x3,53 (2x) EPDM	2304 041	035-159	
30	Retaining clamp (2x)	2122 125	5 100-020	
31	O-Ring Ø16x2 EPDM	2304 016	020-170	
32	Screwed socket	5624 100	) 514-020	
33	Control head KI-Top ASIBus ES/ABSL	5631 203	3 010-000	
	Valve insert compl.	5620 100 830-041	5620 100 820-041	
0	Seal kit	5620 100 839-000	5620 100 829-000	





Horstring 16 D - 76829 Landau

www.guth-vt.de

**2** +49 (0) 6341 5105-0

Fax: +49 (0) 6341 5105-85

sales@guthventiltechnik.de